



# Beverage Fountain

## Stainless Steel Beverage Fountain

### Instructions

Important info: DO NOT RUN FOUNTAIN DRY. SO NOT IMMERSE BASE OF FOUNTAIN IN WATER.

DO NOT FILL WITH BEVERAGES THAT CONTAIN PULP

**\*\*Holds 7 Gallons\*\***

To use: pour beverage into bottom level of fountain, then turn on fountain.

1. If fountain starts and flow of liquid diminishes in a few seconds, check to see if plastic column flow holes are on the bottom; or if the impeller has become loose; or check wing nuts on pump head to see if they are secure.
2. If figurine tower is lopsided, rotate to leveling position.
3. If nozzles are not all flowing properly, raise plastic overflow tube in nozzle tray.
4. On bubbler models if beverage goes more than one inch higher than the bubbler, check to see if the orifice and flow coupling have been enlarged or are missing.
5. If splashing occurs around the figuring tower, check the chain tray to see if any chains are missing.
6. If decorations become dull, clean with soapy water and a small brush.
7. If a pulpy mixture is going to be used, it may be advisable to remove screen from top of pump head.
8. Light bulbs will give you longer life if they are not slashed with liquid when they are on or still warm when emptying beverage from bowl.